



ACESSÓRIOS AUXILIARES PARA DESEMPENO DE CARROÇARIAS

MADE IN FINLAND



PACK SATELLITE

= 1 + 2 + 3 + 4 + 5 + 6 = 052727

1 SATELLITE - Satellite - Satellite Basisbügel-Set



052710



2 KIT MAC PHERSON (A) - Mac Pherson Kit - Befestigungskit-Federbein (McPherson)



052703



3 BARRE POUR TIRER/POUSSER - Push/Pull Bar - Zug/Druck-Stangenset



052673



4 SATELLITE (B) - Bügelverlängerung



052680



5 CINTA DE SEGURANÇA (NÃO SERVE PARA ESTICAR)



044036



6 DOUBLE PINCE SATELLITE (C) - Double Clamp Satellite - Satellite Doppelklemme



052697



Prensa de Chapeiro - 10 Ton.

Made in P.R.C.

10T
052338

