



ACESSÓRIOS AUXILIARES PARA DESEMPENO DE CARROÇARIAS

MADE IN FINLAND



PACK SATELLITE

= 1 + 2 + 3 + 4 + 5 + 6 = 052727

1 SATELLITE

- Satelliite - Satellite Basisbügel-Set



052710



2 KIT MAC PHERSON (A)

- Mac Pherson Kit - BefestigungsKit-Federbein (McPherson)

052703



3 BARRE POUR TIRER/POUSSER

- Push/Pull Bar - Zueh/Stoß-Stangenset



052673



4 SATELLITE (B)

- Bügelverlängerung

052680



5 CINTA DE SEGURANÇA

(NÃO SERVE PARA ESTICAR)

044036



6 DOUBLE PINCE SATELLITE (C)

- Double Clamp Satellite - Satelliite Doppelklammer

052697



Prensa de Chapeiro - 10 Ton.

Made in P.R.C.

10T

052338

